

VERTICS.Shoepatch

Kletterschuh Reparaturset

Climbing Shoe Repair Kit

DE:

- I defekte Stelle mit Schleifpapier aufrauen und säubern
- II Kleber flächig auf die Stelle in Größe des Flickens auftragen
- III mit dem Gummi glattstreichen
- IV 2 Minuten warten
- V Alufolie abziehen
- VI Flicker fest andrücken
- VII besonders an den Rändern andrücken
- VIII nach 10 Minuten Klarsichtfolie abziehen und losklettern

Abgelöste Stellen ggfs. mit Vulkanisierer nachbessern. Je sauberer und genauer gearbeitet wird desto länger hält der aufgebrauchte Gummiflicker.

EN:

- I roughen up damaged area with sandpaper and clean it
- II apply vulcaniser in the size of the patch
- III spread it with the thick rubber pad
- IV wait 2 minutes
- V remove aluminium foil
- VI press the patch firmly
- VII especially press at the edges
- VIII remove transparent foil after 10 minutes and climb on

If necessary, use vulcaniser again at the patch borders. The more exactly the work is done the longer the rubber patch will last on your climbing shoe.



VERTICS

VERTICS.DE

f VERTICS.SLEEVES



I



II



III



IV



V



VI



VII



VIII